



MODEL K333D05-VM

DIGITAL VIBRATION METER KIT

- Turns your smartphone into a portable vibration meter
- Turn-key kit includes mounting hardware and connections
- Pre-programmed ISO vibration severity scales provide instant exceedance feedback
- Cost effective, ideal for beginners or for enhancing broader vibration programs
- No prior training or experience needed
- Averaging and uploaded calibration values ensure quality data
- PDF report generation with images of critical assets


SIMPLIFY PREDICTIVE MAINTENANCE

Harness the power of your smartphone to make simple, accurate and reliable vibration level measurements on critical machinery using the Digital Vibration Meter Kit Model K333D05-VM. Plug the industry exclusive Digiducer® USB Digital Accelerometer into your smartphone for the same advantages that reliability professionals have come to expect with piezoelectric accelerometers. The USB Digital Accelerometer's wide range and accuracy captures machinery vibration events from imbalance to misalignment to bearing faults, gear mesh, and pump cavitation. With a hermetically sealed, stainless steel housing, the Digiducer is built to survive in tough environments.

The VibeCheck smartphone application supplied with the Digital Vibration Meter Kit comes with preset ISO vibration severity scales and alerts the user when vibration readings exceed acceptable thresholds. The application also creates PDF reports with images and isolates high frequency metal-to-metal impacts for easy identification. In-app purchases unlock advanced monitoring capabilities. VibeCheck ensures quality vibration data by automatically uploading the Digital USB Accelerometer's calibration value when connected.

Mounting accessories supplied with the Digital Vibration Meter Kit ensure vibration trends remain accurate even if data is taken by multiple technicians. The kit includes a magnet for curved or flat surfaces, probe tip, carrying pouch and all accessories required to connect to any smartphone.

SPECIFICATIONS	
Performance	
Acceleration Measurement	
Amplitude	20 g pk (196 m/s ²)
High Pass Filter	2 Hz
Fmax	10 kHz
Averages	4
Velocity Measurement	
Amplitude	122 in/s (3100 mm/s)
High Pass Filter	10 Hz
Fmax	1 kHz
Averages	2
Demodulation Measurement ^[1]	
Amplitude	20 g pk (196 m/s ²)
High Pass Filter	2 kHz
Low Pass Filter	10 kHz
Demodulation Fmax	1 kHz
Averages	2
Accuracy	± 3%
Temperature Range ^[2]	14 to 158 F (-10 to 70 C)
Transverse Sensitivity	≤ 5 %
Power Consumption	Less than 45 mA



SYSTEM COMPONENTS ^[3]	
Product Name	Model Number
Digital USB Accelerometer	333D05
M12 to USB-C Cable	529D10
Mounting Stud 1/4-28	081A40
Curved Surface Mount	080A131
Probe Tip 2 in	080A107
USB-C to USB-A Adaptor	A4175
Soft Protective Storage Case	2000X18
VibeCheck App	Free Measurement App

- [1] Useful for bearing fault and gear mesh
 [2] Temperature spec is for sensor, refer to smartphone temperature specs separately
 [3] User supplied smartphone

Specifications at room temperature unless otherwise specified

